



Toolbox Talk

Topic: Beam Wraps and Lifelines

Beam Wrap Use

- Only connect to the D-Ring at the end of the beam wrap – do not basket hitch.
- If you basket the hitch, force may point-load the pass-through ring.
- Choke the sling so that the blue is on the outside. The yellow section is the softener.
- Remove from service if damaged.

Self-Retracting Lifeline (SRL) Storage

- Always store the line completely inside the housing.
- SRLs exposed to the weather can collect moisture and rust.
- Use a nylon tag line to reach the SRL.
- DO NOT tie the snaphook back to the line.

Always review manufacturer instructions for the equipment before use.

